




# Samsung Series 5 3G Chromebook Battery Replacement

This guide will demonstrate how to replace a battery in your Chromebook.

Written By: Helder Avelino



## INTRODUCTION

If your Chromebook is not charging properly or its not turning on, you may need to replace the battery.


---



### TOOLS:

- [Phillips #1 Screwdriver](#) (1)
  - [iFixit Opening Tools](#) (1)
  - [Spudger](#) (1)
-

## Step 1 — Back Cover




- Make sure your Chromebook is powered off before you begin.
- Place the laptop on a flat surface with the bottom side facing up.
- Remove the rubber feet from the bottom of the panel. The easiest way to do this is to use your fingernails to pick them out.
- Remove all the seven screws in the bottom panel.

## Step 2



- Loosen the back cover panel by using the flathead screwdriver or the spudger.


## Step 3



- Once you work your way around, you can remove the panel.



## Step 4 — Battery



- The Chromebook battery can be removed after twisting out three Phillips screws and disconnecting it from the motherboard.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-16 07:16:10 PM.